



Body Camera User Manual
www.spikecam.com
Model: SC09

Body Camera Diagram



Power On/Off

Power on:

1. Press “Power” button, the LED Status Indicator will light up green with power on sound and LCD screen will display welcome message.
2. The camera system will enter into recording standby mode and the LED Status Indicator will remain green.
3. The LCD will display the preview image and your body camera is ready to use.

Note: If you have set the screen saver setting to be 1min/3min/5min, the camera LCD screen will turn off automatically if there is no interaction with body cam.

Power Off:

1. Long press the “Power” button for at least two seconds.
2. The current recording file will be saved to the internal storage and the device will power off.

Recording Video

1. Press the “Video” button and the LED Status Indicator lights up red and flash. The camera will beep audibly.
2. The camera will enter into Video Recording Mode and begin to record. It will save a file every 3min, 5min, 10min or 20min based on your Recording Time setting in the menu.

Note: If you have set the Auto night vision in the system setting list to be Manual. When the lighting is insufficient, press the Up/IR button can enable Night Mode and the IR LEDs. If you have set the Auto night vision to be Auto, when-

Recording Video

the lighting is insufficient, the camera will automatically enable Night Mode and the IR LEDs. It will automatically return to the normal recording mode when light conditions improve.

Stop Recording Video

1. Press the “Video” button until the LED Status Indicator lights up green.
2. The camera will enter Recording Standby Mode.

Recording Audio

1. Press the “Audio” button and the LED Status Indicator flashes green.
2. The camera will beep, and the LCD screen will show a Microphone icon to indicate that the audio recording is ongoing.

Stop Recording Audio

1. Press the “Audio” button and the LED Status Indicator will go back to solid green.
2. The camera will be back to Recording Standby Mode.

Taking a Photo

1. When the camera is in Recording Standby Mode or during Video Recording Mode, press the “Photo” button to take a photo.
2. The LED Status Indicator will flash green one time if it is in Recording Standby Mode. There is a photo capturing sound when taking a photo.

Files Playback

1. Long press the “OK/Menu” button until the camera enters into Playback Mode.
2. To play the currently recording file (video/audio), press the “OK” button again.
3. To play another file, use the “UP” or “Down” button to cycle through the files. Press the “OK” button when you have found the file to play it.

Exit Playback Mode

1. To exit the Playback Mode, **long-press** the “OK/Menu” button.
2. The camera will return to the Recording Standby Mode.

Charging Battery with USB Cable

1. Connect a USB cable with a compatible connector to a computer/wall charger.
2. Connect the USB cable to the USB port on the body camera. When charging the battery while the camera is powered off, the LED Status Indicator will light up red. When the battery is fully charged, the red LED Status Indicator will turn off.

Connect to PC

Connect to PC via mini USB cable, it will display “Connected Computer” on camera LCD. You will find the camera disk on the PC.

Parameter Setting

Short press the OK/Menu button to enter Menu Setting Mode. Use the Up and Down buttons to select the menu item. Press the OK/Menu button to modify the setting. Long press the OK/Menu button to go back or exit Menu Setting Mode.

Submenu details are as below:

Resolution: 2304*1296 20P, 1920x1080 30P, 1440x1080 30P, 1280x720 30P, 800x480 30P, 640x480 30P

Video Quality: Fine, Normal, Economy. (Video quality and continuous recording time will be different)

Loop Recording: Off, On

Recording Time: 3mins, 5mins, 10mins, 20mins

Motion Detection: Off, On

Photo Size: 36M, 21M, 16M, 12M, 10M, 8M, 5M, 2M

Continuous Shoot: Off, 2 sheets, 3 sheets, 5 sheets, 10 sheets

Volume: Off, Low, Medium, High

Screen Saver: Off, 1 Minute, 3 Minutes, 5 Minutes

Auto Power Off: Off, 3 Minutes, 5 Minutes, 10 Minutes

Auto night vision: Manual, Auto

Frequency: 50Hz, 60Hz.

Date/Time: YYYY/MM/DD, HH/MM/SS. Press UP/Down button to select correct date and time, press OK button to confirm each figure. Long press OK button to get back to menu setting list.

Language: English, Traditional Chinese, Simplify Chinese, Japanese, Korean, Russian

Other features:

Package List

1 x Body Camera

1 x Instruction Manual

1 x Charger

1 x USB Cable

1 x Big Shoulder Clip

1 x Small Alligator Clip

Trouble Shooting and Customer Support

1. Camera can not boot. Please charge the camera battery for more than 2 hours first then try to turn on the camera again.
2. Camera can not respond. Please press the Reset button to power off the camera and then restart the camera.(The Reset button is hidden beside the USB Port)
3. Device failed to connect to the computer. Please change to another USB port on another computer or change to another USB cable.

Note: If the above solutions cannot solve the problems, please contact our customer service email:

info@spikecam.com

For more information about this body camera please visit:

<https://www.spikecam.com/sc09>